



| | | | |
|--|-----------|---|-----------|
| (1) <u>Bolt:</u> | FS108307L | (8) <u>Clip:</u> | JHD000020 |
| (2) <u>Hose:</u> | ADU490110 | (9) <u>Sensor, Coolant Temp:</u> | MEK105210 |
| (3) <u>Hose, Radiator Lower:</u> | PCH000961 | (10) <u>Hose, Radiator Upper:</u> | PCH000232 |
| (4) <u>Holder:</u> | PEU000030 | (11) <u>Hose, Thermostat to Heater:</u> | PCH001395 |
| (5) <u>Hose, Engine to Oil Cooler:</u> | PCH000982 | (12) <u>Hose, Heater Return:</u> | PEH000224 |
| (6) <u>Nut:</u> | FN106047L | (13) <u>Coolant Rail:</u> | PFV000032 |
| (7) <u>Holder:</u> | PEU102941 | | |