



- (1) Seal, Plug: IYF500030
- (2) Plug, Oil: IYB500020
- (3) Control Module, T-Case: NNW512070
- (4) Output Flange Kit, Rear: IEA500041
- (5) Solenoid Assembly: IGF500011
- (6) Seal, Rear Flange: IZB500050
- (7) Bolt: FT110357
- (8) Vent Tube: TRG500150
- (9) Bolt: TYP000190
- (10) Output Flange Kit, Front: IEA500031
- (11) Sensor Assembly, Mode: IAB500191
- (12) Seal, Input Shaft: IZB500030
- (13) Seal, Front Output: IZB500040
- (14) Motor Assembly, Shift: IGH500040
- (15) Insulator: IAI500100
- (16) O-Ring Kit: IYX500050
- (17) Bolt: IYP500080
- (18) Transfer Case Assembly: IAB500280