


Brake Lamp Switch

Hydraulic Series II, early IIA (Fits to 5 way junction on frame)	STC1689
Power brake type, Late IIA, III (Fits to top of power brake tower)	575166

Hard Brake Lines



1 Front right brake line 88 & 109 Series III	592364
2 Front left brake line 88 & 109 Series III	565466
3 Master brake cylinder to junction Front circuit dual power 88	595466
Rear circuit dual power 88	595465
4 Junction to rear Single circuit 88	279418
Single circuit 109	279452
Dual power 88	594748
5 Right rear, 88 & 109	592375
6 Left rear, 88 & 109	592374
109 front wheel brake cylinder line (connects top and bottom wheel cylinders)	NRC5347

Junction Fittings

3 Way junction BTB657L



Brake line kits



These are complete copper/bronze line kits with fittings attached. Each line is marked for location. They are easily bent to shape without kinking.

Model 88 single circuit	GL5601
Model 88 dual tandem circuit	GL5610
Model 109 single circuit	GL5602
Model 109 dual tandem circuit	GL5611

Flex hoses

Front flex line right & left	
Series IIA	RTC3353
Series III	RTC5903
Rear flex line Series IIA & III	
88	RTC3386
109	RTC3353
Copper sealing washer for all flex hoses	233220
Nut for all flex hoses	NT606041L
Star lock washer for nut	WF600061L

Clamps and Fittings

Axle clamp 11820L



Metal clamp for rear lines 56666
Rubber grommet for clamp 6860L

